



Radiator Stop Leak



12 x 300 ml

PN2011

USE

AUTOPLUS Radiator Stop Leak stops and prevents leaks in the cooling system with no need for dismantling. It protects all ferrous and non ferrous metals against corrosion.

It is suitable for all types of coolants and any type of engine.

PROPERTIES

AUTOPLUS Radiator Stop Leak:

- Stops and prevents cracks in the engine block, cylinder head, joints and all other leaks in the cooling system.
- Prevents the formation of rust, scale and corrosion.
- Gives an immediate and long-lasting action.

INSTRUCTIONS FOR USE

Shake can very well. When the engine is warm and off, set car heating on maximum position and pour the contents of the can into the radiator expansion tank. Turn on engine at idle speed or drive for 15 min.



Additives & Lubricants SA

24, Chemin du Pré-Moineau
1253 Vandoeuvres - Suisse
Tél.: +41 (0) 22 525 45 30
info@autoplus-additives.com
www.autoplus-additives.com