



Internal engine cleaner

1 ▶ 6L

12 x 300 ml

PN2024

USE

AUTOPLUS Internal Engine Cleaner cleans and dissolves deposits from the engine oil circuit. It acts on the entire circuit (hydraulic system, gearbox, differential).

Compatible with all engines and any engine oil.

INSTRUCTIONS FOR USE

Add the contents of the can into the oil crankcase when the engine is warm and off. Let engine run at idle speed or drive for 15 min. Change oil and replace oilfilter.

PROPERTIES

Internal Engine Cleaner:

- Dissolves and cleans deposits from the engine oil circuit
- Eliminates deposits when draining the oil
- Acts on the entire circuit
- Avoids premature engine wear

CAUTION

Do not exceed the maximum level of engineoil.



Additives & Lubricants SA

24, Chemin du Pré-Moineau
1253 Vandoeuvres - Suisse
Tél.: +41 (0) 22 525 45 30
info@autoplus-additives.com
www.autoplus-additives.com