



# Carburettor, Valve & EGR Cleaner

12 x 400 ml

PN2040

## USE

AUTOPLUS Carburettor, Valve & EGR Cleaner has been designed to answer, specific carburettor and injection system problems such as irregular idling, irregular acceleration, difficult starting, increased fuel consumption and pollution.

## PROPERTIES

Carburettor, Valve & EGR Cleaner:

- Dissolves and eliminates any type of deposit (varnish, gum) .
- Restores acceleration.
- Overcomes irregular idling problems.
- Increases power and responsiveness.
- Limits fuel overconsumption.
- Reduces black smoke and exhaust emissions.
- Does not damage the carburettor.

## INSTRUCTIONS FOR USE

To clean the EGR valve (on diesel and petrol engines): When the engine is warm and running between 1500 and 2000 rpm, spray product into the air intake duct (after the air flow meter) in short 3 second sprayings. Wait for 1 minute between each spraying and regularly rise rpm between 1000 and 3000. After 10 sprayings wait for a longer period. Continue until aerosol is empty.

To clean valves and carburettor (on petrol engines): Remove the air filter, bring the engine up to normal running temperature, spray product on/in the carburettor parts through the air inlet valve until all parts are cleaned. Accelerate repeatedly while doing the cleaning.



## Additives & Lubricants SA

24, Chemin du Pré-Moineau  
1253 Vandoeuvres - Suisse  
Tél.: +41 (0) 22 525 45 30  
info@autoplus-additives.com  
www.autoplus-additives.com